


STI_GL300

Quick Start Guide




1 Charging

Connect the charging plug to the STI_GL300 USB port and plug into an electrical outlet. Allow up to four hours for the STI_GL300 to fully charge




2 Locating IMEI number

Locate IMEI number on top of box. Note that IMEI number is a 15 digit number



3 GPS activation

Open a web browser and navigate to spytecinc.com/gps-activation. Fill out form and click 'submit' button when finished



4 Receiving Account Credentials

Check e-mail account for an e-mail with the subject "New Account for username." Be sure to safely store username and password for future usage



5 Tracking


Navigate to spytecgps.com within web browser and log-in using username and password to begin tracking

Troubleshooting



Q. GPS platform says device is in NJ (last read 400 days ago) but this isn't accurate

- A** This means that your device has not transmitted yet. Turn on the device and make sure the green LED is blinking once every 3 seconds



Q. GPS platform shows a blue screen or the coast of Africa

- A** This means the device has not yet achieved GPS lock. Take it outside for a quick walk or drive and its location should promptly update.



Q. Why does my device say "last updated x days ago"? Is it being used?

- A** This is because of a server timestamp issue with our system. It has nothing to do with the unit or account.



Q. My device has been turned on for sometime. Why is it not updating?

- A** If the green LED is blinking once per second, then the unit's location may not have coverage. Please contact our support.
- B** If the green LED is blinking every three seconds without any update on the site, please contact our support.