



Technical Support

Subject
Ram Promaster Entering "Limp Mode"

System or Parts affected

- Underhood LITE (V300002) Ram Promaster Van

Overview

The Promaster throttle may trigger a "Limp Mode" if engine idle is maintained between 3600 and 4000 RPM for approximately 2 minutes. This causes the engine to idle down and pedal input will not affect engine speed. To disable "Limp Mode" simply shut the engine down and restart.

The VMAC Throttle Control is set to 3,400 RPM which should prevent the engine from entering "Limp Mode".

Document	Version	Department	Revision Details	Revised by	Tech	Engineering	Implemented
EXT-VL-003	A	Tech	Document Release	SP 16 Jul 2015	GB 16 Jul 2015	N/A	16 Jul 2015