

SERVICE



LETTER

Service Letter No. 157

August 1, 1950

SUBJECT: Loose Connections

TO: All Distributors and Owners
Models PA-14, PA-16 and PA-20

It has been brought to our attention that a few Piper airplane owners have experienced trouble with the starter button sticking. We have conducted a thorough investigation and have concluded that there is a slight possibility that the contacts on the button might momentarily stick together as a result of a loose connection in the starting circuit.

It is, therefore, suggested that all owners check, re-clean and retighten all the connections in the starting circuits of the subject model airplanes. This is a safety precaution and should be made a definite part of your annual and 100 hour inspection. Also, don't forget the basic rule for the efficient operation of your electrical equipment and accessories is clean and tight connections.

PIPER AIRCRAFT CORPORATION

A handwritten signature in cursive script, appearing to read "R. Boardman".

Rolland Boardman
Service Manager

RB:dh

PIPER AIRCRAFT CORPORATION, LOCK HAVEN, PA., U. S. A.